

# Washing Machine

## User manual

WW9\*K5\*\*\*\*/WW8\*K5\*\*\*\*/WW7\*K5\*\*\*\*




DC68-03654R-07

**SAMSUNG**

# Contents

---

|  |           |
|--|-----------|
| <b>Safety information</b>  | <b>4</b>  |
| What you need to know about the safety instructions  | 4         |
| Important safety symbols   | 4         |
| Important safety precautions   | 5         |
| Critical installation warnings   | 6         |
| Installation cautions  | 8         |
| Critical usage warnings  | 8         |
| Usage cautions   | 10        |
| Critical cleaning warnings   | 13        |
| <br>   |           |
| <b>Installation</b>  | <b>14</b> |
| What's included  | 14        |
| Installation requirements  | 16        |
| Step-by-step installation  | 18        |
| <br>   |           |
| <b>Before you start</b>  | <b>25</b> |
| Initial settings   | 25        |
| Laundry guidelines   | 25        |
| Detergent drawer guidelines  | 28        |
| <br>   |           |
| <b>Operations</b>  | <b>31</b> |
| Control panel  | 31        |
| Simple steps to start  | 33        |
| Cycle overview   | 34        |
| Special features   | 38        |
| Settings   | 40        |
| <br>   |           |
| <b>Maintenance</b>   | <b>41</b> |
| Eco drum clean  | 41        |
| Smart Check     | 42        |
| Emergency drain  | 43        |
| Cleaning   | 44        |
| Recovery from freezing   | 48        |
| Care against an extended time of disuse  | 48        |

---

|                                    |           |
|------------------------------------|-----------|
| <b>Troubleshooting</b>             | <b>49</b> |
| Checkpoints                        | 49        |
| Information codes                  | 52        |
| <br>                               |           |
| <b>Specifications</b>              | <b>56</b> |
| Fabric care chart                  | 56        |
| Protecting the environment         | 57        |
| Specification sheet                | 58        |
| Information of main washing cycles | 63        |



# Safety information

---

Congratulations on your new Samsung washing machine. This manual contains important information on the installation, use and care of your appliance. Please take some time to read this manual to take full advantage of your washing machine's many benefits and features.

## What you need to know about the safety instructions

---

Please read this manual thoroughly to ensure that you know how to safely and efficiently operate the extensive features and functions of your new appliance. Please store the manual in a safe location close to the appliance for future reference. Use this appliance only for its intended purpose as described in this instruction manual.

Warnings and Important Safety Instructions in this manual do not cover all possible conditions and situations that may occur. It is your responsibility to use common sense, caution and care when installing, maintaining and operating your washing machine.

Because the following operating instructions cover various models, the characteristics of your washing machine may differ slightly from those described in this manual and not all warning signs may be applicable. If you have any questions or concerns, contact your nearest service centre or find help and information online at [www.samsung.com](http://www.samsung.com).

## Important safety symbols

---

What the icons and signs in this user manual mean:

 **WARNING**

Hazards or unsafe practices that may result in severe personal injury, death and/or property damage.

 **CAUTION**

Hazards or unsafe practices that may result in personal injury and/or property damage.

 **NOTE**

Indicates that a risk of personal injury or material damage exists.



These warning signs are here to prevent injury to yourself and others.  
Please follow them explicitly.

After reading this manual, store it in a safe place for future reference.

Read all instructions before using the appliance.

As with any equipment that uses electricity and moving parts, potential hazards exist.  
To safely operate this appliance, familiarize yourself with its operation and exercise care when using it.

## Important safety precautions

### **WARNING**

To reduce the risk of fire, electric shock, or injury to persons when using your appliance, follow basic precautions, including the following:

- 1.** This appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 2. For use in Europe:** This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- 3.** Children should be supervised to ensure that they do not play with the appliance.



# Safety information

---

4. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
5. The new hose-sets supplied with the appliance are to be used and old hose-sets should not be reused.
6. For appliances with ventilation openings in the base, a carpet must not obstruct the openings.
7. **For use in Europe:** Children of less than 3 years should be kept away unless continuously supervised.
8. **CAUTION:** In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

## Critical installation warnings

---

### **WARNING**

The installation of this appliance must be performed by a qualified technician or service company.

- Failure to do so may result in electric shock, fire, an explosion, problems with the product, or injury.

The appliance is heavy, therefore take care when lifting it.

Plug the power cord into a wall socket that meets local electrical specifications. Use the socket for this appliance only, and do not use an extension cord.

- Sharing a wall socket with other appliances using a power strip or extending the power cord may result in electric shock or fire.
- Ensure that the power voltage, frequency, and current are the same as those of the product specifications. Failure to do so may result in electric shock or fire. Plug the power plug into the wall socket firmly.

Remove all foreign substances such as dust or water from the power plug terminals and contact points using a dry cloth on a regular basis.

- Unplug the power plug and clean it with a dry cloth.



- 
- Failure to do so may result in electric shock or fire.

Plug the power plug into the wall socket so that the cord is running towards the floor.

- If you plug the power plug into the socket in the opposite direction, the electric wires within the cable may be damaged and this may result in electric shock or fire.

Keep all packaging materials out of the reach of children as these may be dangerous.

- If a child places a bag over its head, it may suffocate.

When the appliance, power plug or power cord is damaged, contact your nearest service centre.

This appliance must be properly grounded.

Do not ground the appliance to a gas pipe, plastic water pipe, or telephone line.

- This may result in electric shock, fire, an explosion, or problems with the product.
- Never plug the power cord into a socket that is not grounded correctly and make sure that it is in accordance with local and national regulations.

Do not install this appliance near a heater or any inflammable material.

Do not install this appliance in a humid, oily or dusty location, or in a location exposed to direct sunlight or water (rain drops).

Do not install this appliance in a location exposed to low temperatures.

- Frost may cause the tubes to burst.

Do not install this appliance in a location where gas may leak.

- This may result in electric shock or fire.

Do not use an electric transformer.

- This may result in electric shock or fire.

Do not use a damaged power plug, damaged power cord, or loose wall socket.

- This may result in electric shock or fire.

Do not pull or excessively bend the power cord.

Do not twist or tie the power cord.

Do not hook the power cord over a metal object, place a heavy object on the power cord, insert the power cord between objects, or push the power cord into the space behind the appliance.

- This may result in electric shock or fire.

Do not pull the power cord when unplugging the power plug.

- Unplug the power plug by holding the plug.
- Failure to do so may result in electric shock or fire.



# Safety information

---

This appliance should be positioned so that the power plug, the water supply taps, and the drain pipes are accessible.

## Installation cautions

---

### CAUTION

This appliance should be positioned in such a way that the power plug is easily accessible.

- Failure to do so may result in electric shock or fire due to electric leakage.

Install your appliance on a solid, level floor that can support its weight.

- Failure to do so may result in abnormal vibrations, movement, noise, or problems with the product.

## Critical usage warnings

---

### WARNING

If the appliance is flooded, turn off the water & power supplies immediately and contact your nearest service centre.

- Do not touch the power plug with wet hands.
- Failure to do so may result in electric shock.

If the appliance generates a strange noise, a burning smell, or smoke, unplug the power plug immediately and contact your nearest service centre.

- Failure to do so may result in electric shock or fire.

In the event of a gas leak (such as propane gas, LP gas, etc.), ventilate immediately without touching the power plug. Do not touch the appliance or power cord.

- Do not use a ventilating fan.
- A spark may result in an explosion or fire.

Do not let children play in or on the washing machine. In addition, when disposing of the appliance, remove the washing machine door lever.

- If trapped inside the product, children may suffocate to death.

Make sure to remove the packaging (sponge, styrofoam) attached to the bottom of the washing machine before using it.

Do not wash items contaminated with gasoline, kerosene, benzene, paint thinner, alcohol or other inflammable or explosive substances.

- This may result in electric shock, fire, or an explosion.





---

Do not open the washing machine door by force while it is operating (high-temperature washing/drying/spinning).

- Water flowing out of the washing machine may result in burns or cause the floor to be slippery. This may result in injury.
- Opening the door by force may result in damage to the product or injury.

Do not insert your hand under the washing machine while an operation is in progress.

- This may result in injury.

Do not touch the power plug with wet hands.

- This may result in electric shock.

Do not turn the appliance off by unplugging the power plug while an operation is in progress.

- Plugging the power plug into the wall socket again may cause a spark and result in electric shock or fire.

Do not let children or the infirm use this washing machine without proper supervision. Do not let children climb in or onto the appliance.

- This may result in electric shock, burns or injury.

Do not insert your hand or a metal object under the washing machine while it is operating.

- This may result in injury.

Do not unplug the appliance by pulling the power cord. Always grip the plug firmly and pull it straight out of the outlet.

- Damage to the power cord may cause a short-circuit, fire and/or electric shock.

Do not attempt to repair, disassemble, or modify the appliance yourself.

- Do not use a fuse (such as copper, steel wire, etc.) other than a standard fuse.
- When the appliance needs to be repaired or reinstalled, contact your nearest service centre.
- Failure to do so may result in electric shock, fire, problems with the product, or injury.

If the water supply hose comes loose from the water tap and floods the appliance, unplug the power plug.

- Failure to do so may result in electric shock or fire.

Unplug the power plug when the appliance is not being used for long periods of time or during a thunder or lightning storm.

- Failure to do so may result in electric shock or fire.

If any foreign substance enters into the appliance, unplug the power plug and contact your nearest Samsung Customer Service.

- This may result in electric shock or fire.



# Safety information

---

Do not let children (or pets) play in or on your washing machine. The washing machine door does not open easily from the inside and children may be seriously injured if trapped inside.

## Usage cautions

---

### CAUTION

When the washing machine is contaminated by a foreign substance such as detergent, dirt, food waste, etc., unplug the power plug and clean the washing machine using a damp, soft cloth.

- Failure to do so may result in discolouration, deformation, damage, or rust.

The front glass may be broken by a strong impact. Take care when using the washing machine.

- If the glass is broken, it may result in injury.

After a water supply failure or when reconnecting the water supply hose, open the water tap slowly.

Open the water tap slowly after a long period of non-use.

- The air pressure in the water supply hose or the water pipe may damage a product part or result in a water leak.

If a draining error occurs during an operation, check if there is a draining problem.

- If the washing machine is used when it is flooded because of a draining problem, it may result in electric shock or fire.

Insert the laundry into the washing machine completely so that the laundry does not get caught in the door.

- If laundry gets caught in the door, it may result in damage to the laundry or the washing machine, or result in a water leak.

Turn the water supply off when the washing machine is not being used.

- Ensure that the screws on the water supply hose connector are properly tightened.

Ensure that the rubber seal and front door glass are not contaminated by a foreign substance (e.g. waste, thread, hair, etc.).

- If a foreign substance is caught in the door or the door is not completely closed, it may cause a water leak.

Open the water tap and check if the water supply hose connector is firmly tightened and that there is no water leak before using the product.



- If the screws on the water supply hose connector are loose, it may result in a water leak.

The product you have purchased is designed for domestic use only.

Using the product for business purposes qualifies as a product misuse. In this case, the product will not be covered by the standard warranty provided by Samsung and no responsibility can be attributed to Samsung for malfunctions or damages resulting from such misuse.

Do not stand on the appliance or place objects (such as laundry, lighted candles, lighted cigarettes, dishes, chemicals, metal objects, etc.) on the appliance.

- This may result in electric shock, fire, problems with the product, or injury.

Do not spray volatile material such as insecticide onto the surface of the appliance.

- As well as being harmful to humans, this may result in electric shock, fire or problems with the product.

Do not place objects that generate electromagnetic fields near the washing machine.

- This may result in injury due to a malfunction.

Water drained during a high-temperature wash or drying cycle is hot. Do not touch the water.

- This may result in burns or injury.

If the water temperature is high before drain, it take time until the temperature goes down, and it can be different depending on internal temperature.

Do not wash, spin, or dry water-proof seats, mats, or clothing (\*) unless your appliance has a special cycle for washing these items.

(\*): Woollen bedding, rain covers, fishing vests, ski pants, sleeping bags, diaper covers, sweat suits, and bicycle, motor cycle and car covers, etc.

- Do not wash thick or hard mats even if the washing machine mark is on the care label. This may result in injury or damage to the washing machine, walls, floor, or clothing due to abnormal vibrations.
- Do not wash throw rugs or doormats with rubber backing. The rubber backing may come off and stick to inside the drum, and this may result in malfunction such as a drainage error.

Do not operate the washing machine when the detergent drawer is removed.

- This may result in electric shock or injury due to a water leak.

Do not touch the insides of the drum during or just after drying as it is hot.

- This may result in burns.



# Safety information

---

Do not insert your hand into the detergent drawer.

- This may result in injury as your hand may be caught by the detergent input device.
- The liquid detergent guide (applicable models only) is not used for powder detergent. Remove the guide when using powder detergent.

Do not place any objects (such as shoes, food waste, animals) other than laundry into the washing machine.

- This may result in damage to the washing machine, or injury and death in the case of pets due to the abnormal vibrations.

Do not press the buttons using sharp objects such as pins, knives, fingernails, etc.

- This may result in electric shock or injury.

Do not wash laundry contaminated by oils, creams or lotions usually found in skincare shops or massage clinics.

- This may cause the rubber seal to become deformed and result in a water leak.

Do not leave metal objects such as safety pins, hair pins or bleach in the drum for long periods of time.

- This may cause the drum to rust.
- If rust starts appearing on the surface of the drum, apply a (neutral) cleansing agent to the surface and use a sponge to clean it. Never use a metal brush.

Do not use dry cleaning detergent directly and do not wash, rinse, or spin laundry contaminated by dry cleaning detergent.

- This may result in spontaneous combustion or ignition due to the heat from the oxidation of the oil.

Do not use water from water cooling/heating devices.

- This may result in problems with the washing machine.

Do not use natural hand-washing soap for the washing machine.

- If it hardens and accumulates inside the washing machine, it may result in problems with the product, discolouration, rust, or bad odours.

Place socks and brassieres in a washing net and wash them with the other laundry.

Do not wash large laundry items such as bedding in the washing net.

- Failure to do so may result in injury due to abnormal vibrations.

Do not use hardened detergent.

- If it accumulates inside the washing machine, it may result in a water leak.

Make sure that the pockets of all the clothing items to be washed are empty.



- 
- Hard, sharp objects such as coins, safety pins, nails, screws, or stones can cause extensive damage to the appliance.

Do not wash clothing with large buckles, buttons or other heavy metal objects.

Sort the laundry by colour on the basis of its colorfastness and select the recommended cycle, water temperature and additional functions.

- This may result in discolouration or fabric damage.

Take care that children's fingers are not caught in the door when you close it.

- Failure to do so may result in injury.

### Critical cleaning warnings

---

#### **WARNING**

Do not clean the appliance by spraying water directly onto it.

Do not use a strong acidic cleaning agent.

Do not use benzene, thinner or alcohol to clean the appliance.

- This may result in discolouration, deformation, damage, electric shock or fire.

Before cleaning or performing maintenance, unplug the appliance from the wall socket.

- Failure to do so may result in electric shock or fire.

# الغسالة

## دليل المستخدم

WW9\*K5\*\*\*\*/WW8\*K5\*\*\*\*/WW7\*K5\*\*\*\*

**SAMSUNG**



DC68-03654R-07

# المحتويات

|    |   |
|----|---|
| ٤  | <b>معلومات السلامة</b>  |
| ٤  | ما يجب أن تعرفه حول إرشادات السلامة   |
| ٤  | رموز السلامة المهمة   |
| ٥  | احتياطات السلامة المهمة   |
| ٦  | تحذيرات التركيب الهامة  |
| ٧  | تنبيهات التركيب   |
| ٧  | تحذيرات الاستخدام الهامة  |
| ٩  | تنبيهات الاستخدام   |
| ١١ | تحذيرات التنظيف الهامة  |
| ١٢ | <b>التركيب</b>  |
| ١٢ | مكونات الغسالة  |
| ١٤ | متطلبات التركيب   |
| ١٦ | تفاصيل عملية التركيب  |
| ٢٣ | <b>قبل بدء التشغيل</b>  |
| ٢٣ | الإعدادات الأولية   |
| ٢٣ | إرشادات الغسيل  |
| ٢٦ | الإرشادات الخاصة بدرج المنظف  |
| ٢٩ | <b>العمليات</b>   |
| ٢٩ | لوحة التحكم   |
| ٣١ | خطوات بسيطة لبدء التشغيل  |
| ٣٢ | نظرة عامة على الدورات   |
| ٣٥ | الميزات الخاصة  |
| ٣٧ | الإعدادات   |
| ٣٨ | <b>الصيانة</b>  |
| ٣٨ | تنظيف الخوض  |
| ٣٨ | Smart Check  |
| ٣٩ | تصريف الطوارئ   |
| ٤٠ | التنظيف   |
| ٤٤ | استرداد الحالة الطبيعية بعد التجمد  |
| ٤٤ | الحذر من عدم الاستخدام لفترة طويلة  |

|    |                                  |
|----|----------------------------------|
| ٤٥ | <b>استكشاف المشاكل وحلها</b>     |
| ٤٥ | تعليمات الفحص                    |
| ٤٨ | رموز المعلومات                   |
| ٥١ | <b>المواصفات</b>                 |
| ٥١ | جدول العناية بالأقمشة            |
| ٥٢ | حماية البيئة                     |
| ٥٣ | بيان المواصفات                   |
| ٦٢ | معلومات حول دورات الغسل الأساسية |



## معلومات السلامة

تهانينا على شرائك غسالة Samsung الجديدة. يتضمن هذا الدليل معلومات مهمة حول عملية تركيب الجهاز واستخدامه والعناية به. لذا، يُرجى قراءة هذا الدليل بعناية لتتمكن من الاستفادة الكاملة من الميزات والفوائد العديدة المتوفرة بالغسالة.

### ما يجب أن تعرفه حول إرشادات السلامة


يرجى قراءة هذا الدليل بعناية لضمان معرفة كيفية تشغيل الميزات والوظائف المتعددة لغسالتك الجديدة بسلامة وفعالية. كما يجب الاحتفاظ به في مكان آمن بالقرب من الجهاز للرجوع إليه في المستقبل. لا تستخدم هذا الجهاز إلا للغرض المخصص له على النحو الموضح في دليل الإرشادات الذي بين يديك.

لا تغطي التحذيرات وإرشادات السلامة المهمة الواردة في هذا الدليل جميع الظروف والمواقف المحتملة حدوثها. لذا، يجب التعامل بحذر وانتباه وعناية عند تركيب الغسالة وصيانتها وتشغيلها.

ونظرًا لأن إرشادات التشغيل التالية تنطبق على طُرز متعددة، فإن خصائص الغسالة التي تستعملها قد تختلف قليلاً عن تلك الموصوفة في هذا الدليل. كما أن بعض علامات التحذير المذكورة قد تكون غير قابلة للتطبيق. إذا كان لديك أي أسئلة أو استفسارات، فاتصل بأقرب مركز خدمة. أو ابحث عن التعليمات والمعلومات عبر الإنترنت على الموقع [www.samsung.com](http://www.samsung.com).

### رموز السلامة المهمة

تشير الرموز والعلامات الموجودة في دليل المستخدم الذي بين يديك إلى ما يلي:

 تحذير

المخاطر أو الممارسات غير الآمنة التي قد ينتج عنها التعرض لإصابة شخصية خطيرة أو الوفاة أو أضرار بالملكات.

 تنبيه

المخاطر أو الممارسات غير الآمنة التي قد ينتج عنها التعرض لإصابة شخصية أو أضرار بالملكات.

 ملاحظة

تشير إلى وجود خطر من التعرض لإصابة شخصية أو ضرر مادي.

تهدف علامات التحذير هذه إلى منع حدوث إصابات لك وللآخرين.

لذا، يرجى اتباعها بعناية.

وبعد قراءة هذا الدليل، احتفظ به في مكان آمن للرجوع إليه في المستقبل.

اقرأ جميع الإرشادات أولاً قبل استخدام الجهاز.

يوجد احتمال التعرض للمخاطر، كما هو الحال مع أي أجهزة تستخدم الطاقة الكهربائية والأجزاء المتحركة. ولتشغيل هذا الجهاز بأمان، يجب عليك التعرف على طريقة تشغيله وتوخي الحذر أثناء استخدامه.

## احتياطات السلامة المهمة



**لتقليل احتمالات نشوب حريق أو التعرض لصدمة كهربائية أو حدوث إصابة جسدية لأشخاص أثناء استخدام الجهاز، اتبع احتياطات السلامة الأساسية التالية:**

١. يجب عدم استخدام هذا الجهاز من قبل ذوي الإعاقات البدنية أو الحسية أو العقلية أو من تنقصهم المعرفة والخبرة (بما في ذلك الأطفال)، إلا إذا كانوا تحت إشراف شخص يوفر لهم إرشادات حول استخدام الجهاز، ويكون مسؤولاً عن سلامتهم.
٢. الاستخدام في أوروبا: يمكن أن يستخدم هذا الجهاز الأطفال الذين تبدأ أعمارهم من ٨ سنوات فيما أكثر. بالإضافة إلى الأشخاص الذين يتسمون بقدرات عضلية أو حسية أو عقلية قليلة أو أولئك الذين تنقصهم المعرفة والخبرة إذا كانوا تحت الإشراف وعلى علم بالإرشادات التي تتعلق باستخدام الجهاز بطريقة آمنة وفهم المخاطر المتضمنة في عملية الاستخدام. ويجب ألا يتم السماح للأطفال بالعبث بالجهاز. كما يجب عدم السماح للأطفال بالقيام بأعمال التنظيف أو الصيانة التي يقوم بها المستخدم دون إشراف.
٣. يجب مراقبة الأطفال لضمان عدم عبثهم بالجهاز.
٤. في حالة تلف سلك التيار الكهربائي، يجب تغييره من قبل الشركة المصنّعة أو وكيل الصيانة الخاص بها أو أي فني مؤهل لتجنب التعرض لأي خطر.
٥. يجب استخدام مجموعات الخراطيم الجديدة المرفقة بالغسالة وعدم استخدام مجموعات الخراطيم القديمة مرة أخرى.
٦. بالنسبة للأجهزة التي تحتوي على فتحات تهوية بقاعدتها، يجب تجنب سد السجاد لهذه الفتحات.
٧. الاستخدام في أوروبا: يجب أن يبتعد الأطفال أقل من ٣ سنوات عن الغسالة ما لم يخضعوا للمراقبة اللصيقة.

## معلومات السلامة

٨. تنبيه: لتجنب وجود خطر بسبب إعادة الضبط غير المقصود للقاطع الحراري، يجب ألا يتم تزويد هذا الجهاز بالطاقة من خلال جهاز فصل ووصل خارجي -مثل المؤقت- أو توصيله بدائرة كهربائية يتم تشغيلها وإيقاف تشغيلها بصورة منتظمة من قبل مرفق الخدمة العامة.

### تحذيرات التركيب الهامة



- يجب تركيب هذا الجهاز بواسطة فني مؤهل أو شركة صيانة متخصصة.
- قد ينتج عن الفشل في اتباع هذه التعليمات حدوث صدمة كهربائية أو نشوب حريق أو انفجار أو مشاكل تتعلق بالمنتج أو التعرض للإصابة. يجب توخي الحذر عند رفع الغسالة لأن وزنها ثقيل.
- وصل سلك التيار الكهربائي بمقبس حائط يستوفي المواصفات الكهربائية المحلية. لا تستخدم المقبس إلا لتشغيل هذا الجهاز ولا تستخدم سلك تمديد.
- قد تؤدي مشاركة مأخذ الحائط مع أجهزة أخرى باستخدام مشترك كهرباء أو تمديد سلك التيار الكهربائي إلى حدوث صدمة كهربائية أو نشوب حريق.
- تأكد من تطابق كل من الجهد الكهربائي والتردد والتيار مع القياسات الخاصة بمواصفات المنتج؛ قد يؤدي عدم الالتزام بذلك إلى التعرض لصدمة كهربائية أو نشوب حريق. لذا، يجب التأكد من توصيل قابس التيار الكهربائي بمقبس الحائط بإحكام.
- قم بإزالة أي مواد غريبة، مثل الأتربة أو الماء من أطراف قابس التيار الكهربائي ونقاط الاتصال باستخدام قطعة قماش جافة بانتظام.
- افصل قابس التيار الكهربائي ونظفه باستخدام قطعة قماش جافة.
- قد يؤدي عدم الالتزام بذلك إلى التعرض لصدمة كهربائية أو نشوب حريق.
- أدخل قابس التيار الكهربائي في مأخذ الحائط بحيث يكون اتجاه السلك ناحية الأرض.
- إذا قمت بإدخال قابس الطاقة في المأخذ في الاتجاه المعاكس، فقد تتلف الأسلاك الكهربائية الموجودة داخل الكبل وقد يؤدي هذا الأمر إلى حدوث صدمة كهربائية أو نشوب حريق.
- احتفظ بجميع مواد التعبئة والتغليف بعيدة تمامًا عن متناول أيدي الأطفال. نظرًا لأنها قد تمثل خطرًا عليهم.
- قد يؤدي وضع الطفل لكيس من أكياس التغليف فوق رأسه إلى إصابته بالاختناق.
- في حالة تلف الجهاز أو قابس التيار الكهربائي أو سلك التيار الكهربائي، فاتصل بأقرب مركز خدمة.
- يجب توصيل الجهاز بطرف أرضي بشكل سليم.
- لا تقم بتوصيل الجهاز بماسورة غاز أو ماسورة ماء بلاستيكية أو سلك تليفون.
- قد يؤدي ذلك إلى التعرض لصدمة كهربائية أو نشوب حريق أو حدوث انفجار أو مشكلات بالمنتج.
- يجب عدم توصيل سلك التيار الكهربائي بمأخذ لم يتم توصيله بطرف أرضي بشكل صحيح. وتأكد من أن ذلك يتم وفقًا للقوانين المحلية والدولية.
- يجب عدم تركيب هذا الجهاز بالقرب من سخان أو أي مواد ملتهبة.
- لا تضع هذا الجهاز في مكان رطب أو به زيت أو أي مكان به غبار أو في مكان عرضة لضوء الشمس المباشر أو الماء (قطرات المطر).
- يجب عدم تركيب هذا الجهاز في مكان معرض لدرجات حرارة منخفضة.

- قد يؤدي الجليد إلى انفجار الأنابيب.
- لا تقم بتركيب هذا الجهاز في موقع يكون به تسرب للغاز.
- قد ينتج عن هذا الأمر حدوث صدمة كهربائية أو نشوب حريق.
- لا تستخدم محوّلًا كهربائيًا.
- قد ينتج عن هذا الأمر حدوث صدمة كهربائية أو نشوب حريق.
- لا تستخدم قابس تيار كهربائي أو سلك تيار كهربائي تالفًا أو مقبس حائط غير مُحكم.
- قد ينتج عن هذا الأمر حدوث صدمة كهربائية أو نشوب حريق.
- ولا تسحب سلك التيار الكهربائي أو تثنيه بشدة.
- ولا تقم بلي سلك التيار الكهربائي أو ربطه.
- لا تعلق سلك التيار الكهربائي فوق شيء معدني أو تضع شيئًا ثقيلًا فوقه أو تمرر سلك التيار الكهربائي بين أشياء أو تدفعه في المساحة الموجودة خلف الجهاز.
- قد ينتج عن هذا الأمر حدوث صدمة كهربائية أو نشوب حريق.
- لا تجذب سلك التيار الكهربائي عند فصل قابس التيار الكهربائي.
- افصل قابس التيار الكهربائي عن طريق سحب القابس.
- قد يؤدي عدم الالتزام بذلك إلى التعرض لصدمة كهربائية أو نشوب حريق.
- يجب وضع الجهاز بحيث يسهل الوصول إلى قابس التيار الكهربائي وصنابير توريد الماء وأنباب تصريف الماء.

## تنبيهات التركيب

### ⚠ تنبيه

- يجب تركيب هذا الجهاز بطريقة يمكن من خلالها الوصول إلى قابس التيار الكهربائي بسهولة.
- قد يؤدي عدم الالتزام بهذا الأمر إلى حدوث صدمة كهربائية أو نشوب حريق نتيجة لتسرب الكهرباء.
- يجب تركيب الجهاز على أرضية مستوية وصلبة تتحمل وزنه.
- قد ينتج عن عدم الالتزام بهذه التعليمات حدوث اهتزازات أو حركات أو ضوضاء أو مشاكل غير طبيعية بالمنتج.

## تحذيرات الاستخدام الهامة

### ⚠ تحذير

- في حالة تعرض الجهاز لكمية زائدة من الماء، أوقف توريد المياه والتيار الكهربائي بشكل فوري، واتصل بأقرب مركز خدمة.
- لا تلمس قابس التيار الكهربائي بيدين مبلتين.
- قد يؤدي عدم الالتزام بذلك إلى حدوث صدمة كهربائية.
- في حالة إصدار الجهاز لضوضاء غير طبيعية أو رائحة اشتعال أو دخان، افصل قابس التيار الكهربائي فورًا واتصل بأقرب مركز خدمة.
- قد يؤدي عدم الالتزام بذلك إلى التعرض لصدمة كهربائية أو نشوب حريق.

## معلومات السلامة

في حالة وجود تسرب للغاز (مثل غاز البروبان أو الغاز النفطي المتسالم، وما إلى ذلك)، يجب تهوية المكان فوراً دون لمس قابس التيار الكهربائي. ولا تلمس الجهاز أو سلك التيار الكهربائي.

- لا تستخدم مروحة تهوية.
- قد تحدث شرارة وتؤدي إلى حدوث صدمة كهربائية أو نشوب حريق.
- لا تدع الأطفال يلعبون فوق الغسالة أو بداخلها. كذلك، يجب فك حامل مقبض الغسالة عند التخلص من الجهاز.
- قد يُحبس الطفل داخل الغسالة ويتعرض للاختناق حتى الموت.
- تأكد من إزالة الغلاف (الإسفننج / الفوم) الموجود أسفل الغسالة قبل استخدامها.
- يجب عدم غسل العناصر الملوثة بالمجازولين أو الكيروسين أو البنزين أو مخفف الدهان أو الكحول أو أي مواد أخرى قابلة للاشتعال أو الانفجار.
- قد ينتج عن هذا الأمر حدوث صدمة كهربائية أو نشوب حريق أو انفجار.
- يجب عدم فتح باب الغسالة بالقوة أثناء التشغيل (الغسل/التجفيف/العصر عند درجة حرارة عالية).
- قد ينتج عن اندفاع الماء خارج الغسالة الإصابة بحروق أو تصبح الأرض منزلقة. قد ينتج عن ذلك حدوث إصابات.
- قد يؤدي فتح الباب بالقوة إلى تلف المنتج أو حدوث إصابة.
- لا تضع يدك أو أسفل الغسالة أثناء تشغيلها.
- قد ينتج عن ذلك حدوث إصابات.
- لا تلمس قابس التيار الكهربائي بيدين مبللتين.
- قد ينتج عن هذا الأمر التعرض لصدمة كهربائية.
- لا تقم بإيقاف تشغيل الغسالة بفصل قابس التيار الكهربائي أثناء تشغيلها.
- قد يؤدي إدخال قابس التيار الكهربائي مرة أخرى في مأخذ الحائط إلى حدوث شرارة ينتج عنها صدمة كهربائية أو نشوب حريق.
- يجب عدم السماح للأطفال أو الأفراد غير المؤهلين باستخدام هذه الغسالة دون إشراف كامل. كما يجب عدم السماح للأطفال بالصعود فوق الغسالة.
- قد ينتج عن ذلك حدوث صدمة كهربائية أو حروق أو إصابة.
- لا تضع يدك أو أي كائن معدني أسفل الغسالة أثناء تشغيلها.
- قد ينتج عن ذلك حدوث إصابات.
- لا تفصل الجهاز عن طريق سحب سلك التيار الكهربائي. بل يجب دائماً مسك قابس الطاقة بإحكام وسحبه بشكل مستقيم من مخرج التيار الكهربائي إلى الخارج.
- قد يؤدي تلف سلك التيار الكهربائي إلى حدوث قصر في الدائرة الكهربائية و/أو حريق و/أو التعرض لصدمة كهربائية.
- لا تحاول إصلاح الجهاز أو فكّه أو تعديله بنفسك.
- يجب عدم استخدام أي صمام كهربائي (مثل النحاس أو سلك معدني وما إلى ذلك) بخلاف الصمام الكهربائي القياسي.
- اتصل بأقرب مركز خدمة عند الحاجة إلى إصلاح الجهاز أو إعادة تركيبه.
- قد يؤدي الفشل في اتباع هذه التعليمات إلى حدوث صدمة كهربائية أو نشوب حريق أو مشاكل تتعلق بالمنتج أو التعرض للإصابة.
- عندما يصبح خرطوم التزود بالماء غير محكم وينتج عنه تسريب للماء في الجهاز يجب فصل سلك التيار الكهربائي من مأخذ الكهرباء.
- قد يؤدي عدم الالتزام بذلك إلى التعرض لصدمة كهربائية أو نشوب حريق.
- يجب فصل قابس التيار الكهربائي في حالة عدم استخدام الجهاز لفترات طويلة أو أثناء العواصف الرعدية أو البرق.



- قد يؤدي عدم الالتزام بذلك إلى التعرض لصدمة كهربائية أو نشوب حريق.
- في حالة دخول أي مادة غريبة إلى الجهاز، قم بفصل قابس التيار الكهربائي واتصل بأقرب مركز خدمة لشركة Samsung.
- قد ينتج عن هذا الأمر حدوث صدمة كهربائية أو نشوب حريق.
- لا تدع الأطفال (أو الحيوانات الأليفة) يلعبون داخل الغسالة أو فوقها؛ حيث إنه لا يمكن فتح باب الغسالة بسهولة من الداخل. وقد يصاب الأطفال بإصابات بالغة الخطورة في حالة احتباسهم بداخلها.

## تنبيهات الاستخدام



- عند وجود مادة غريبة داخل الغسالة، مثل المنظفات أو الأتربة أو مخلفات الطعام وما إلى ذلك، افصل قابس التيار الكهربائي ونظف الغسالة باستخدام قطعة قماش رطبة وناعمة.
- قد يؤدي عدم الالتزام بهذا الأمر إلى حدوث تغيير في الألوان أو التشويه أو التلف أو الصدأ.
- قد ينكسر الزجاج الأمامي نتيجة لحدوث اصطدام قوي، لذا، يجب الحرص عند استخدام الغسالة.
- قد تحدث إصابة في حالة انكسار الزجاج.
- عند حدوث فشل في توريد الماء أو عند إعادة توصيل خرطوم توريد الماء، يجب فتح الصنبور ببطء.
- افتح الصنبور ببطء عند الاستخدام بعد فترة طويلة من عدم الاستخدام.
- قد يؤدي ضغط الهواء في خرطوم توريد الماء أو ماسورة الماء إلى تلف جزء من الغسالة أو حدوث تسرب للماء.
- في حالة حدوث خطأ في عملية التصريف أثناء التشغيل، تحقق من عدم وجود مشكلة تتعلق بالتصريف.
- قد يؤدي استخدام الغسالة أثناء تسرب المياه منها نتيجة وجود مشكلة بالتصريف إلى الإصابة بصدمة كهربائية أو نشوب حريق نتيجة لحدوث تسرب كهربائي.
- يجب إدخال الملابس بالكامل في الغسالة بحيث لا تعلق بالباب.
- قد يؤدي ذلك إلى تلف الملابس أو الغسالة، أو قد ينتج عنه حدوث تسرب للماء.
- أغلق الصنبور في حالة عدم استخدام الغسالة.
- تأكد من ربط مسامير خرطوم توريد الماء بإحكام.
- تأكد من عدم التصاق أي مواد غريبة بالخاجز المطاطي والزجاج الأمامي للباب (على سبيل المثال، مخلفات أو خيوط أو شعر، وما إلى ذلك).
- في حالة التصاق أي مادة غريبة في الباب أو لم يتم إغلاقه جيداً، فقد يتسبب ذلك في حدوث تسرب للماء.
- يجب فتح الصنبور والتحقق من إحكام وصلة خرطوم الماء وعدم وجود تسرب للماء قبل استخدام المنتج.
- في حالة عدم إحكام ربط المسامير أو وصلة خرطوم توريد الماء، قد يحدث تسرب للماء.
- تم تصميم المنتج الذي قمت بشرائه للاستخدام المنزلي فقط.
- يُعد استخدام المنتج لأغراض تجارية سوء استخدام له، وفي هذه الحالة، لا تتم تغطية المنتج من خلال الضمان القياسي الذي تقدمه شركة Samsung، كما أن شركة Samsung لا تتحمل أي مسؤولية عن الأعطال أو الخسائر التي تنجم عن سوء الاستخدام.
- لا تطفئ فوق الجهاز أو تضع أشياء فوقه (مثل، ملابس الغسيل أو شموع مضاءة أو سجائر مشتعلة أو أطباق أو مواد كيميائية أو أشياء معدنية، وما إلى ذلك).



## معلومات السلامة

- قد ينتج عن هذا الأمر الإصابة بصدمة كهربائية أو نشوب حريق أو حدوث مشاكل بالمنتج أو وقوع إصابات.
    - يجب عدم رش مواد متطايرة، مثل المبيدات الحشرية، فوق سطح الجهاز.
    - بالإضافة إلى أن هذا الأمر يضر بالإنسان، فقد ينتج عنه أيضًا الإصابة بصدمة كهربائية أو نشوب حريق أو حدوث مشاكل بالمنتج.
  - لا تضع أشياء ينتج عنه مجالات كهرومغناطيسية بالقرب من الغسالة.
  - قد ينتج عن هذا حدوث إصابات جسدية نتيجة وجود خلل في وظائف التشغيل.
  - الماء الذي يتم تصريفه أثناء الغسل بدرجات حرارة عالية أو أثناء دورة التجفيف يكون ساخنًا، فلا تلمسه.
  - قد ينتج عن هذا الأمر حدوث حروق أو إصابات.
- إذا كانت درجة حرارة الماء مرتفعة قبل التصريف، فستستغرق وقتًا حتى تنخفض درجة حرارتها، وقد تختلف درجة الحرارة حسب درجة الحرارة الداخلية.
- يجب عدم غسل مفروشات المقاعد أو السجاد أو الأقمشة (\*) المقاومة للماء أو عصرها أو جفيفها ما لم يكن جهازك متضمنًا دورة خاصة لغسلها.
- (\*) المفروشات الصوفية أو الأغذية المقاومة للأمطار أو سترات الصيد أو بنطلونات التزلج أو حقائب النوم أو أغطية الحفاضات أو الملابس الرياضية أو أغطية الدراجات والدراجات البخارية والسيارات، وما إلى ذلك.
- يجب عدم غسل السجاد السميك أو الثقيل حتى في حالة وجود علامة الغسالة على بطاقة العناية بالمنتج. قد يؤدي هذا الأمر إلى حدوث إصابة أو تلف بالغسالة أو بالحوائط أو بالأرضية أو بالملابس نتيجة للاهتزازات غير الطبيعية.
  - لا تغسل السجاد الوبر أو مسحة الأرجل التي تحتوي على المطاط. فقد ينسلخ المطاط ويعلق بالحاوية من الداخل. مما يؤدي إلى حدوث قصور في أداء المنتج كأن حدث مشكلة في التصريف.
- يجب عدم تشغيل الغسالة في حالة عدم وجود درج المنظف.
- قد ينتج عن هذا الأمر حدوث صدمة كهربائية أو إصابة جسدية نتيجة لتسرب الماء.
  - يجب عدم لمس الحاوية من الداخل أثناء عملية التجفيف أو بعدها مباشرة؛ حيث يكون ساخنًا.
  - قد ينتج عن هذا الأمر الإصابة بحروق.
- لا تضع يدك في درج المنظف.
- قد ينتج عن هذا الأمر حدوث إصابات، حيث يمكن أن تصاب يديك عن طريق جهاز إضافة المنظف.
  - لا تُستخدم حاوية المنظف السائل (الطُرز الملائمة فقط) مع مسحوق الغسيل. لذا، قم بفك الحاوية عند استخدام مسحوق الغسيل.
- تجنب وضع أي أشياء (مثل الأحذية وبقايا الطعام والحيوانات) غير الملابس داخل الغسالة.
- قد يؤدي هذا الأمر إلى تلف الغسالة أو حدوث إصابة ووفاء في حالة وجود حيوانات أليفة نتيجة للاهتزازات غير الطبيعية.
  - لا تضغط على الأزرار باستخدام أدوات حادة، مثل المسامير أو السكاكين أو الأظافر، وما إلى ذلك.
  - قد ينتج عن ذلك حدوث صدمة كهربائية أو إصابة.
- يحظر غسيل الملابس التي تحتوي على زيوت أو كرميات أو مستحضرات سائلة، والتي توجد في متاجر مستحضرات العناية بالبشرة أو عيادات التدليك عادةً.
- قد ينتج عن هذا الأمر تشوه الحاجز المطاطي ويؤدي إلى تسرب الماء.
  - يجب عدم ترك أي أشياء معدنية، مثل الدبابيس أو دبابيس الشعر أو مواد التبييض، في الحاوية لفترات طويلة من الوقت.
  - قد يؤدي هذا الأمر إلى صدأ الحاوية.
  - وفي حالة بدء ظهور الصدأ على سطح الحاوية، قم بتنظيف سطحها باستخدام سائل تنظيف (متعادل) وإسفنجة، ولا تستخدم فرشاة معدنية مطلقًا.

- لا تستخدم منظفًا جافًا بشكل مباشر، ولا تغسل الملابس أو تشطفها أو تعصرها في حالة إضافة منظف جاف إليها.
- قد يؤدي هذا الأمر إلى حدوث اشتعال فوري نتيجة للحرارة الناتجة عن تأكسد الزيت.
- لا تستخدم الماء القادم من أجهزة تبريد/تسخين الماء.
- قد ينتج عن هذا الأمر حدوث مشاكل في الغسالة.
- لا تستخدم صابون غسل يدين متعادل بالغسالة.
- في حالة حدوث التراكم وتيبس داخل الغسالة، قد يحدث مشاكل تتعلق بالمنتج، مثل تغير اللون أو الصدأ أو تولد رائحة كريهة.
- يمكنك وضع الجوارب وحملات الصدر داخل شبكة الغسيل وغسلها مع بقية الملابس.
- لا تغسل عناصر الغسيل كبيرة الحجم، مثل المفروشات، في شبكة الغسيل.
- يؤدي عدم الالتزام بهذا الأمر إلى حدوث إصابة نتيجة للاهتزازات غير الطبيعية.
- لا تستخدم منظفًا متبيسًا.
- قد يحدث تسرب للماء في حالة تراكم المنظف المتبيس داخل الغسالة.
- تأكد من إفراغ جميع جيوب الملابس التي سيتم غسلها.
- قد تتسبب الأشياء الصلبة والحادة مثل العملات المعدنية أو الدبابيس أو المسامير أو المسامير القلاووظ أو الأحجار في إحداث أضرار بالغة بالجهاز.
- لا تقم بغسل الملابس المرزودة بإبزعات أو أزرار كبيرة الحجم أو الأشياء المعدنية الأخرى ثقيلة الوزن.
- افرز الغسيل حسب اللون وفقًا لثباته ثم حدد الدورة المناسبة ودرجة الحرارة المناسبة والوظائف الإضافية.
- قد ينتج عن هذا الأمر تغير اللون أو تلف في النسيج.
- توخ الحذر حتى لا تنحشر أصابع الأطفال بالباب عند إغلاقه.
- قد يؤدي عدم توخي الحذر إلى حدوث إصابة.

## تحذيرات التنظيف الهامة



- لا تنظف الجهاز برش الماء عليه مباشرة.
- لا تستخدم منظفًا حمضيًا قويًا.
- لا تستخدم البنزين أو مرقق الطلاء أو الكحول لتنظيف الجهاز.
- قد ينتج عن هذا الأمر تغيير في اللون أو تشويه أو تلف أو حدوث صدمة كهربية أو نشوب حريق.
- افصل قابس الجهاز من مقبس الحائط قبل تنظيفه أو صيانته.
- قد يؤدي عدم الالتزام بذلك إلى التعرض لصدمة كهربائية أو نشوب حريق.