

Sunbeam

**ALINEA SELECT
TEMPERATURE SELECT KETTLE**

User Guide



KE2800

Contents

Sunbeam's Safety Precautions	1
Features Of Your Kettle	2
Using Your Kettle	3
Lower Temperature Select Mode	4
Error Alert	4
Mute Function	4
Suggested Water Temperatures	4
Energy Saving Hints And Tips	5
If The Kettle Boils Dry	5
Sunbeam's 3-Way Safety System	5
Care And Cleaning	6

Important instructions – retain for future use.

تأكد من تفهم احتياطات السلامة المذكورة اعلاه

請務必理解上述的安全預防措施。

Assurez-vous que les précautions ci-dessus relatives à la sécurité sont bien comprises

Versichern Sie sich, dass die obenstehenden Sicherheitsmaßnahmen Verstanden werden

Βεβαιώνετε πως οι παραπάνω προφυλάξεις ασφαλείας γίνονται κατανοητές

Pastikan bahwa tindakan-tindakan keselamatan seperti di atas dimengerti anda

Accertatevi che le suddette norme di sicurezza siano comprese a dovere

上記の注意事項をよくお読みになり、安全を御確認ください

Уверете се дека погоре споменатите мерки на претпазливост се добро разбрани

Asegúrese de que las precauciones de seguridad precedentes sean bien comprendidas

کاری بکنید کہ احتیاطهای بالا حتماً درک بشوند

ต้องแน่ใจว่า ข้อควรระวังเรื่องความปลอดภัยข้างต้น เป็นที่เข้าใจกันดี

Yukarda belirtilen güvenlik önlemlerinin anlaşıldığından emin olunuz

Xin kiểm chắc rằng những biện pháp làm an toàn kể trên được hiểu rõ

Sunbeam's Safety Precautions

SAFETY PRECAUTIONS FOR YOUR SUNBEAM KETTLE.

- Always operate the kettle on a flat, level surface and do not operate unless the element is fully immersed.
- Boiling water will scald. Do not leave a boiling or hot kettle near or where children may touch it.
- Do not leave the power cord near the edge of a bench top where children may touch or pull it.
- Boiling water may be ejected if overfilled.

Sunbeam is very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercise care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:


- Read carefully and save all the instructions provided with an appliance.
- Always turn the power off at the power outlet before you insert or remove a plug. Remove by grasping the plug - do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service person.
- Always use your appliance from a power outlet of the voltage (A.C. only) marked on the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The temperature of accessible surfaces may be high when the appliance is operating. Even after use, the heating element surface is subject to residual heat.
- Never leave an appliance unattended while in use.

- Do not open lid while water is boiling.
- Do not operate the kettle without water.
- Always turn the power off and unplug the cord while the kettle is NOT in use.
- Your kettle must only be used with the power base supplied.
- Do not move kettle while switched on.
- Avoid spillage on the connector power base.

- This appliance has been designed to boil quality drinking water. Do not use the kettle for any other purposes, including boiling any other liquids.
- Any misuse of this product may lead to potential injury.
- Do not place an appliance on or near a hot gas flame, electric element or on a heated oven.
- Do not place on top of any other appliance.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been damaged in any manner. If damage is suspected, return the appliance to the nearest Sunbeam Appointed Service Centre for examination, repair or adjustment.
- For additional protection, Sunbeam recommend the use of a residual current device (RCD) with a tripping current not exceeding 30mA in the electrical circuit supplying power to your appliances.
- Do not immerse the appliance in water or any other liquid unless recommended.
- Appliances are not intended to be operated by means of an external timer or separate remote control system.
- This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.

If you have any concerns regarding the performance and use of your appliance, please visit the Sunbeam Website or contact the Sunbeam Consumer Service Line. Ensure the above safety precautions are understood.

Features of your Kettle



- | | |
|---|-------------------------------|
| 1. Spout | 6. Stop button |
| 2. Filter (behind spout) | 7. Countdown timer |
| 3. Pull off lid | 8. Temperature select buttons |
| 4. Water level window | 9. Just Boil button |
| 5. 360° rotational power base with cord storage | |

Using your kettle

⚠ If this kettle is filled above the maximum level mark, hot water may be ejected from the spout during boiling. Beware of steam coming from the spout or lid especially during refilling. Never open the lid when the kettle is boiling.

1. Plug the power base into a suitable power outlet. NOTE: The kettle will turn on and enter stand by mode until one of the buttons on the base unit is pressed.
2. Remove your kettle from the power base before filling it with water.
3. Fill your kettle with water. You can fill it through the spout or by opening the lid. Don't overfill your kettle and always ensure that there is sufficient water in your kettle for it to operate correctly. This is approximately 250ml or 1 teacup full. Always check the water level when your kettle is positioned on its power base.
4. If opened previously, close the lid and place your kettle back on the base.
5. The temperature touch pad on the base unit of the kettle allows you to select your required temperature of water for the beverage you are making. Choose your desired temperature by touching one of the temperature buttons; the selected temperture will illuminate and heating will start.
6. The countdown timer on the base of the unit will indicate the time left until your kettle reaches the desired temperature. The length of time the water takes to get to temperature will vary depending on the volume of water in the kettle and the temperature selected. NOTE: If the selected temperature is changed during heating the lights and timer on the base unit will automatically adjust themselves. NOTE: Due to the variable way in which heat energy transfers through water the timer lights may not extinguish at a steady rate. This is normal and has no effect on the water temperature.
7. When your kettle is heating, the stop button, water level window and selected temperature will illuminate. NOTE: During heating the temperature of the water will be indicated by the illuminated temperature button. As the temperature increases the buttons will illuminate one by one.
8. When the water reaches the selected temperature, your kettle will play a short tune and the illumination will flash to indicate the water is ready. (You have the option to mute the tune).
9. Kettle will switch off automatically after temperature is reached or if the kettle is removed from the base during operation.
10. You may also switch your kettle off manually at any time by pressing the stop button again.
11. When the kettle is on the base it will continue to monitor the water temperature after the selected temperature has been reached. The current water temperature will be indicated on the base unit with a slow pulsing illumination of the temperature button. Once the water temperature drops below 80°C the base unit will enter standby mode.

LOWER TEMPERATURE SELECT MODE

You can even set a temperature that is lower than the current temperature while the kettle is cooling, and the kettle will let you know when it is ready! For example, if the kettle has boiled and is indicating 100°C you can press

(for example) 90°C and its light will be permanently on. When the water has cooled to 90°C your kettle will play a short tune and the illumination will flash to indicate the water is ready.

ERROR ALERT

If the kettle jug is removed from the base and you attempt to use the base unit, the kettle will sound an error tone and the base unit lights will pulse 3 times. To use the kettle place the jug back onto the base.

MUTE FUNCTION

This function allows you to mute all sounds.

The mute function can be activated by holding down the stop button for 3 seconds. There will be a sound after 3 seconds to confirm the mute setting has been activated.

To deactivate the mute function, hold the stop button for 3 seconds. There will be a sound to confirm the mute setting has been deactivated.

SUGGESTED WATER TEMPERATURES

Beverage	Recommended Temperature
Green Tea	80°C
White Tea	85°C
Oolong Tea	90°C
Black Tea	90°C-100°C
Herbal Teas	90°C-100°C
Instant Coffee	95°C
Hot Chocolate	90°C-100°C

ENERGY SAVING HINTS AND TIPS

A Sunbeam® kettle, if used correctly, is a very energy efficient device. Why not try some of these energy saving tips:

Only boil the water you need. Overfilling your kettle by one cup is the equivalent to using an energy saving light bulb for one hour!

It is not always necessary to reboil your kettle. For example, one litre of water will still be at 90°C after five minutes - the perfect temperature for a cup of oolong tea.

Only heat the water to the temperature required for your chosen beverage.

IF THE KETTLE BOILS DRY

If the kettle is operated with insufficient water a built-in fail-safe device will automatically switch it off.

Unplug your kettle and allow it to cool. When it has cooled down sufficiently the safety device will reset itself.

Sunbeam's 3-Way Safety System



Our 3-Way Safety System ensures that your kettle will:

1. Automatically switch off after boiling.

For convenience, safety and energy efficiency, your Sunbeam kettle will automatically switch off after boiling.

2. Cut-out for boil-dry protection.

If the kettle is operated without water, it will automatically cut-out, preventing any damage to the element.

If this occurs, allow the kettle to cool before filling with cold water and re-boiling.

3. Shut-down in case of overheating.

In the event of overheating, the kettle will automatically shut down to prevent further damage. Should this occur, take your kettle to a Sunbeam Service Centre or Appointed Service Agent.

Care and Cleaning

Always disconnect the kettle from the power outlet before cleaning.

Never immerse the kettle switch area, cord or power base in water, or allow moisture to come into contact with these parts.

Descal Your Kettle Regularly.

Mineral deposits in tap water solidify when the water is heated; lime scale may be white, coloured, even rusty-looking and is normally visible. Phosphate scale isn't generally visible however it may cause the water to appear cloudy when heated. This may cause the interior of the water gauge to discolour, cause overheating, trigger the boil-dry cut-out mechanism or even reduce the kettle's life.

Even in soft water areas it is important to descale your kettle regularly to help maintain its lifecycle.

NOTE: Failure to descale products regularly can be deemed as negligent handling and any faults caused by mineral build up will not be covered by the Sunbeam 12 Month Guarantee.

To remove this build-up, use Sunbeam Liquid Descaler, a simple to use, non-toxic cleaner available from Sunbeam Appointed Service Agents.

Alternatively:

1. Fill the kettle with 1 cup of white vinegar and the remainder with water and allow to stand overnight. **DO NOT BOIL.**
2. Empty the solution from the kettle. Any stains remaining inside the spout can be removed by rubbing with a damp cloth. Fill the kettle with clean water, bring to boil and then discard the water. Repeat and the kettle will then be ready to use.

Cleaning the concealed heating element

This kettle features a non-corrosive stainless steel heating element. Over time, scale may build up on the concealed element inside the kettle, causing discolouration that may have the appearance of rust. Be assured this is not rust. If this occurs clean with a Scotchbrite® scourer or similar and a suitable abrasive cleaning cream. Rinse and clean thoroughly with tap water before using your kettle again.

To clean the exterior

The surface of the kettle may be wiped over with a damp cloth and polished with a soft dry cloth.

Take care not to knock or damage the paintwork, as this may result in areas where the finish does not retain its original character. Clean the exterior of the product by wiping with a soft, lint-free damp cloth.

CAUTION: Do not use any polishing agents, chemicals, steelwool or abrasive cleaning products to clean the outside of the kettle as these can damage the appearance.

To clean the mesh filter

CAUTION: Before removing or refitting the filter, switch off the kettle and empty it. Allow it to cool completely, then unplug the power base from the main supplied socket. Never operate the kettle without the filter fitted.

Open the Lid. Grasp the top of the mesh filter and pull upwards to remove. Wash in warm soapy water and dry thoroughly before replacing in the kettle.

CAUTION: To prevent damage to the appliance do not use alkaline cleaning agents when cleaning, use a soft cloth and mild detergent.



This Sunbeam product is covered by a 12 month replacement or repair warranty, which is in addition to your rights under the Australian Consumer Law (if your product was purchased in Australia) or New Zealand Consumer Guarantees Act (if your product was purchased in New Zealand).

Upon receipt of your claim, Sunbeam will seek to resolve your difficulties or, if the product is defective, advise you on how to obtain a replacement or refund.

To assist us in managing warranty claims, we recommend you register your product as soon as practicable after purchase by creating a MySunbeam account on our website and uploading a copy of your original receipt.

In order to make a claim under our warranty, you must have the original proof of purchase documentation for the product and present it when requested (if not already uploaded to our website).

Should your product develop any defect within 12 months of purchase because of faulty materials or workmanship, we will replace or repair it, at our discretion, free of charge. A product presented for repair may be replaced by a refurbished product of the same type rather than being repaired. Refurbished parts may be used to repair the product.

Our replacement or repair warranty only applies where a defect arises as a result of faulty material or workmanship during the warranty period. Your warranty does not cover misuse or negligent handling (including damage caused by failing to use the product in accordance with this instruction booklet), accidental damage, or normal wear and tear.

Your warranty does not:

- cover freight or any other costs incurred in making a claim, consumable items, accessories that by their nature and limited lifespan require periodic renewal (such as filters and seals) or any consequential loss or damage; or

- cover damage caused by:
 - power surges, power dips, voltage supply problems, or use of the product on incorrect voltage;

- servicing or modification of the product other than by Sunbeam or an authorised Sunbeam service centre;
- use of the product with other accessories, attachments, product supplies, parts or devices that do not conform to Sunbeam specifications; or
- exposure of the product to abnormally corrosive conditions; or

- extend beyond 3 months if the product is used in commercial, industrial, educational or rental applications.

The benefits given to you by our warranty are in addition to other rights and remedies under law in relation to the product.

In Australia our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Our goods also come with guarantees that cannot be excluded under the New Zealand Consumer Guarantees Act.

If your warranty claim is not accepted, we will inform you and if requested to do so by you, repair the product provided you pay the usual charges for such repair. You will also be responsible for all freight and other costs.

Should your product require repair or service after the warranty period, contact your nearest Sunbeam service centre. For a complete list of Sunbeam's service centres, visit our website or call our customer service line for advice on 1300 881 861 in Australia, or 0800 786 232 in New Zealand.

Should you experience any difficulties with your product during the warranty period, please contact our customer service line for advice on 1300 881 861 in Australia, or 0800 786 232 in New Zealand.

Australia

www.sunbeam.com.au
1300 881 861
Suite 1, Level 1,
13 Lord Street,
Botany NSW 2019
Australia

New Zealand

www.sunbeam.co.nz
0800 786 232
Level 6, Building 5,
Central Park,
660-670 Great South Road,
Greenlane, Auckland
New Zealand

Note

Note

Need help with your appliance?

Contact our customer service team or visit our website for information and tips on getting the most from your appliance.

Australia | **visit** www.sunbeam.com.au
phone 1300 881 861
mail Suite 1, Level 1,
13 Lord Street,
Botany NSW 2019
Australia

New Zealand | **visit** www.sunbeam.co.nz
phone 0800 786 232
mail Level 6, Building 5,
Central Park,
660–670 Great South Road,
Greenlane, Auckland.

Newell Australia Pty Ltd | ABN 68 075 071 233

Sunbeam is a registered trade mark.

Made in China to Sunbeam's specification.

Due to minor changes in design or otherwise,
the product you buy may differ slightly from the one shown here.
Approved by the appropriate electrical regulatory authorities.

©Copyright Sunbeam 2020.

01/2020

GCDS-SUN-SL